



- a. Position the safety adapter at the bottom of the scanner in that way that the three highlighted recesses of the adapter fit exactly over those of the scanner. Ensure that the adapter is fitted correctly
- b. Hand-tighten the Safety Adapter to the scanner using the M4 screws and the central 5/8" screw.